



METAL FORMS CORPORATION  
SINCE 1909

# Easy steps to fast accurate forming for straight curbs and gutters



**Step 1**  
Set the first back form to line and lock it to the pins. Slide the next back form in, raise it to the line on the stake in the forward position, drive stakes in the other pockets.



**Step 2**  
After the first ten feet are formed with two division plates, only one division plate is required for subsequent forms.



**Step 3**  
Place the gutter face form under the division plate clips using them as templates, then lock the forms to the form pins.



**Step 4**  
Slide the curb face form into the hold down clips on the division plates. No threading, wedging or locking.



**Step 5**  
Two top spreaders lock the curb face forms to the back form to complete the forming.



**All you need for 100 L.F.**  
10 pcs - Back Forms  
10 pcs - Gutter Forms  
10 pcs - Curb Face Forms  
20 pcs - Top Spreaders  
11 pcs - Full Division Plates